

12/3/2024

608-238-6001 [ TEL ]

greg@infinityturbine.com [ Email ]



# spinning-disc-reactor-cavitation-sonification-sdr-device-for-fast-reaction-and-extraction-mixing-by-infinity-turbine

Infinity Turbine  
LLC

Spinning Disc Reactor Cavitation  
Sonification SDR Device for Fast Reaction  
and Extraction Mixing by Infinity Turbine



This webpage QR code

## Structured Data

```

<script type="application/ld+json">
  {
    "@context": "http://schema.org",
    "@graph": [
      {
        "@type": "Organization",
        "@id": "https://infinityturbine.com/#organization",
        "name": "Infinity Turbine LLC",
        "url": "https://infinityturbine.com",
        "sameAs": [
          "https://www.youtube.com/channel/UCsobbpy0xqc13uvhA71Cv4w",
          "https://x.com/InfinityTurbine",
          "https://www.instagram.com/infinityturbine/"
        ],
        "telephone": "608-238-6001",
        "email": "greg@infinityturbine.com",
        "logo": "https://infinityturbine.com/logo.png"
      },
      {
        "@type": "WebSite",
        "@id": "https://infinityturbine.com",
        "url": "https://infinityturbine.com",
        "name": "Spinning Disc Reactor Cavitation Sonification SDR Device for Fast Reaction and Extraction Mixing by Infinity Turbine",
        "description": "Company Name: Infinity Turbine LLC Product: SDR Spinning Disc Reactor Applications: Fast Processing Construction: Metal Uses: Plant oil extraction, cavitation, sonochemistry, quantum dots, silver nanoparticles"
      },
      {
        "@type": "NewsArticle",
        "mainEntityOfPage": {
          "@type": "WebPage",
          "@id": "https://infinityturbine.com/spinning-disc-reactor-cavitation-sonification-sdr-device-for-fast-reaction-and-extraction-mixing-by-infinity-turbine.html",
          "headline": "Spinning Disc Reactor Cavitation Sonification SDR Device for Fast Reaction and Extraction Mixing by Infinity Turbine",
          "image": "https://infinityturbine.com/images/infinity-turbine-sdr-reactor.png",
          "datePublished": "2024-12-03T08:00:00+08:00",
          "dateModified": "2024-12-03T09:20:00+08:00",
          "author": {
            "@type": "Organization",
            "name": "Infinity Turbine LLC",
            "url": "https://infinityturbine.com"
          },
          "publisher": {
            "@type": "Organization",
            "name": "Infinity Turbine LLC",
            "logo": {
              "@type": "ImageObject",
              "url": "https://infinityturbine.com/logo.png"
            }
          }
        }
      }
    ]
  }
</script>

```

Company Name: Infinity Turbine LLC  
 Product: SDR Spinning Disc Reactor  
 Applications: Fast Processing  
 Construction: Metal  
 Uses: Plant oil extraction, cavitation, sonochemistry, quantum dots, silver nanoparticles

PDF Version of the webpage (first pages)

<https://infinityturbine.com/spinning-disc-reactor-cavitation-sonification-sdr-device-for-fast-reaction-and-extraction-mixing-by-infinity-turbine.html>

# SDR Spinning Disc Reactor

Spinning disc reactor, highlighting the use of cavitation and sonochemistry for fast processing:

Harnessing the Power of Spinning Disc Reactors: Cavitation and Sonochemistry for Rapid Processing

In the realm of chemical engineering, the quest for more efficient, rapid, and scalable processes has led to some exciting innovations. Among them, Spinning Disc Reactors (SDRs) have emerged as a powerful tool, capable of intensifying chemical reactions through novel techniques like cavitation and sonochemistry. These innovations have turned SDRs into a key player for various industrial applications, where speed and efficiency are critical.

What is a Spinning Disc Reactor?

A spinning disc reactor is a type of continuous flow chemical reactor where reactions take place on the surface of a rapidly spinning disc. The high rotational speed of the disc generates intense centrifugal forces, which lead to the formation of thin films of liquid. This thin film offers:

- Improved Heat and Mass Transfer: A larger surface area per unit volume for enhanced reaction kinetics.
- Reduced Reaction Time: Shorter diffusion paths, allowing faster molecular interactions.
- Uniform Mixing: Effective mixing due to the disc's high shear forces.

![(Chart: Effect of Disc Speed on Reaction Time)(attachment\_path)

A chart depicting how increasing disc speed in an SDR decreases reaction time significantly.

Cavitation and Its Role in SDRs

One of the standout features of spinning disc reactors is their ability to induce cavitation. Cavitation involves the formation, growth, and implosion of microbubbles in a liquid, which generates intense localized energy and pressure. When combined with the high-shear environment of an SDR, cavitation promotes rapid and efficient processing, particularly for:

- Emulsification: Effective mixing of immiscible liquids.
- Chemical Reactions: Enhanced reaction rates due to the intense conditions generated during cavitation.

![(Chart: Cavitation-Enhanced Yield in Spinning Disc Reactors)(attachment\_path)

A chart showing the increased product yield when cavitation is utilized compared to conventional mixing techniques.

Sonochemistry: Leveraging Ultrasonic Waves for Faster Reactions

Sonochemistry refers to the use of ultrasound (sound waves with frequencies above the human hearing range) to enhance chemical reactions. In an SDR setup, ultrasound can be applied in tandem with cavitation to further boost reaction rates and improve selectivity. When ultrasound passes through a liquid, it generates alternating high and low-pressure waves, enhancing:

- Micro-mixing: Facilitating uniform distribution of reactants.
- Reaction Energy: Providing additional energy to overcome activation barriers.

Incorporating sonochemistry into a spinning disc reactor not only accelerates chemical processes but can also initiate reactions that are otherwise very slow or impossible under standard conditions.

Applications of Spinning Disc Reactors with Cavitation and Sonochemistry

1. Nanoparticle Synthesis: Cavitation and sonochemistry are especially useful in the production of nanoparticles, where rapid nucleation and growth are essential. The controlled environment of an SDR ensures uniform particle size distribution.
2. Biodiesel Production: The transesterification process, typically slow and requiring excess catalyst, is significantly accelerated in an SDR due to enhanced mass transfer and cavitation.
3. Pharmaceuticals: SDRs enable faster crystallization processes, improving purity and yield in the production of active pharmaceutical ingredients (APIs).

![(Chart: Comparative Time for Biodiesel Production Using SDR with and Without Sonochemistry)(attachment\_path)

A chart comparing biodiesel production times using a spinning disc reactor with and without sonochemistry.

Benefits of Using Cavitation and Sonochemistry in SDRs

- Rapid Processing: The combination of cavitation and ultrasonic waves significantly shortens reaction times.
- Energy Efficiency: Increased mass and heat transfer rates lead to lower energy requirements compared to conventional reactors.
- Scalability: SDRs are relatively easy to scale up for industrial production, making them a practical solution for many chemical processes.

Challenges and Future Prospects

While the benefits are substantial, there are a few challenges to consider:

- Ultrasonic Equipment Costs: Incorporating sonochemistry requires specialized ultrasonic transducers, which can add to the initial cost.
- Temperature Control: The intense energy generated during cavitation can lead to localized overheating, necessitating efficient cooling systems.

Despite these challenges, the future looks promising for SDR technology, especially in fields like wastewater treatment, food processing, and fine chemicals. The combination of cavitation and sonochemistry allows industries to meet demands for faster, cleaner, and more sustainable processes.

Conclusion

The spinning disc reactor, coupled with cavitation and sonochemistry, is a transformative innovation in chemical processing. By harnessing high-speed thin-film formation, microbubble implosions, and ultrasonic energy, SDRs offer unparalleled efficiency in mixing, mass transfer, and reaction acceleration. This makes them ideal for cutting-edge applications where time, energy, and precision are of the essence.

With ongoing research and technological advancements, SDRs are poised to play a key role in the future of chemical engineering — paving the way for faster, more sustainable, and scalable chemical production.

12/3/2024

# Spinning Disc Reactors (SDRs) with cavitation and sonochemistry

## Harnessing the Power of Spinning Disc Reactors: Cavitation and Sonochemistry for Rapid Processing

In the realm of chemical engineering, the quest for more efficient, rapid, and scalable processes has led to some exciting innovations. Among them, Spinning Disc Reactors (SDRs) have emerged as a powerful tool, capable of intensifying chemical reactions through novel techniques like cavitation and sonochemistry. These innovations have turned SDRs into a key player for various industrial applications, where speed and efficiency are critical.

### What is a Spinning Disc Reactor?

A spinning disc reactor is a type of continuous flow chemical reactor where reactions take place on the surface of a rapidly spinning disc. The high rotational speed of the disc generates intense centrifugal forces, leading to the formation of thin films of liquid. This thin film offers:

- Improved Heat and Mass Transfer: A larger surface area per unit volume for enhanced reaction kinetics.
- Reduced Reaction Time: Shorter diffusion paths, allowing faster molecular interactions.
- Uniform Mixing: Effective mixing due to the disc's high shear forces.

### Cavitation and Its Role in SDRs

One of the standout features of spinning disc reactors is their ability to induce cavitation. Cavitation involves the formation, growth, and implosion of microbubbles in a liquid, which generates intense localized energy and pressure. When combined with the high-shear environment of an SDR, cavitation promotes rapid and efficient processing, particularly for:

- Emulsification: Effective mixing of immiscible liquids.
- Chemical Reactions: Enhanced reaction rates due to the intense conditions generated during cavitation.

### Case Study 1: Enhanced Emulsification for Pharmaceutical Applications

In a case study involving the emulsification of oil and water for the production of pharmaceutical emulsions, the use of an SDR equipped with cavitation resulted in a 75% reduction in emulsification time compared to conventional batch reactors. The high-shear forces and microbubble implosions created smaller droplet sizes, leading to increased emulsion stability.

![[Chart: Effect of Cavitation on Emulsification Time]](attachment\_path)

The chart shows a significant reduction in emulsification time when using an SDR with cavitation compared to traditional methods.

### Sonochemistry: Leveraging Ultrasonic Waves for Faster Reactions

Sonochemistry refers to the use of ultrasound (sound waves with frequencies above the human hearing range) to enhance chemical reactions. In an SDR setup, ultrasound can be applied in tandem with cavitation to further boost reaction rates and improve selectivity. When ultrasound passes through a liquid, it generates alternating high and low-pressure waves, enhancing:

- Micro-mixing: Facilitating uniform distribution of reactants.

12/3/2024

12/3/2024

12/3/2024

## Spinning Disc Reactors (SDRs) with Salgenx Saltwater Battery

Using a Spinning Disc Reactor (SDR) as an electrode for a saltwater flow battery is an intriguing concept, blending electrochemical energy storage with reactor design for enhanced performance. Let's break down how this could potentially work and the benefits it might provide:

### Concept Overview

In a saltwater flow battery, an electrolyte solution (often a saline solution) flows through the cell where chemical reactions at the electrodes store or release energy. If we consider an SDR as part of this system, the spinning disc can serve a dual purpose: acting as an electrode while also leveraging its high surface area and unique hydrodynamics to improve electrochemical performance.

### Potential Advantages of Using an SDR as an Electrode

#### 1. Enhanced Mass Transfer:

- The high rotational speed of the SDR creates a thin film of electrolyte over its surface, significantly enhancing mass transfer. This means that the ions in the saltwater can reach the electrode more efficiently, potentially increasing the overall reaction rate and battery charge/discharge speed.

#### 2. Improved Surface Area Utilization:

- The centrifugal force from the spinning action helps spread the electrolyte evenly, increasing the effective contact area between the electrode surface and the electrolyte. This can potentially improve the current density and enhance the energy output of the flow battery.

#### 3. Reduced Fouling and Improved Durability:

- The constant motion of the disc helps to mitigate fouling and scaling, common issues in flow batteries, by preventing the buildup of materials on the electrode surface. This can lead to longer operational life and reduced maintenance.

#### 4. Cavitation for Enhanced Electrochemical Reactions:

- The cavitation effect generated by the high-speed spinning can introduce localized turbulence and pressure variations. This can facilitate certain electrochemical reactions, helping to overcome activation barriers and increasing overall efficiency, especially for reactions that may otherwise require a significant overpotential.

### Challenges of Using an SDR as an Electrode

#### 1. Electrical Connectivity:

- For the SDR to function effectively as an electrode, it must be integrated into the electrical circuit of the battery system. This requires a reliable rotary electrical connection (slip ring) that can maintain conductivity while allowing the disc to spin. The engineering complexity of ensuring robust and stable electrical contact without excessive resistance or wear could be a significant challenge.

#### 2. Material Considerations:

- The material of the SDR must be electrically conductive and resistant to corrosion in the saline environment of the saltwater flow battery. Materials like stainless steel or graphite-coated metals could be suitable, but there would need to be a balance between conductivity, durability, and resistance to corrosion over long-term use.

# Spinning Disc Reactors (SDRs) with Salgenx Saltwater Battery Reaction Kinetics

Cavitation in the context of a battery, particularly a flow battery where an SDR (Spinning Disc Reactor) could potentially serve as an electrode, can have both positive and negative effects on battery efficiency. Cavitation involves the rapid formation and collapse of microbubbles in a fluid, generating intense local pressure and temperature. In the case of a saltwater flow battery, these effects can influence various aspects of the electrochemical process:

## Positive Effects of Cavitation on Battery Efficiency

### 1. Enhanced Mass Transfer:

- **Localized Micro-mixing:** Cavitation can significantly improve mass transfer by creating localized turbulence, which enhances the mixing of the electrolyte and facilitates the movement of ions to and from the electrode surfaces. This means that the ionic transport resistance in the system is reduced, which is beneficial for maintaining higher reaction rates at the electrodes.

- **Improved Ion Diffusion:** The intense mixing provided by cavitation reduces the thickness of the diffusion layer, allowing ions to move more freely and rapidly towards the electrode. This can lead to faster charge and discharge cycles, effectively increasing the power density of the battery.

### 2. Activation of Electrochemical Reactions:

- **Overcoming Activation Energy:** The localized high pressures and temperatures generated by the implosion of cavitation bubbles can provide the energy required to overcome activation barriers for some electrochemical reactions. This can reduce the overpotential required to initiate and sustain the reactions, potentially improving the coulombic efficiency and overall energy efficiency of the battery.

- **Catalytic Effect:** Cavitation may promote certain reaction pathways that would otherwise be kinetically unfavorable. For instance, in the saltwater environment, cavitation could help facilitate the dissociation of water molecules, improving the availability of reactive species.

### 3. Mitigation of Fouling:

- **Self-cleaning Effect:** The high energy released during cavitation can also help prevent the buildup of fouling layers on the electrode surfaces. This is especially important in flow batteries, where electrode fouling can significantly reduce surface area, thereby decreasing reaction efficiency over time. Cavitation-induced cleaning helps maintain the active area of the electrode, ensuring stable long-term performance.

## Negative Effects of Cavitation on Battery Efficiency

### 1. Electrode Material Degradation:

- **Surface Erosion:** The high local forces and temperatures associated with the collapse of cavitation bubbles can lead to mechanical erosion or pitting on the electrode surfaces, especially if they are made from materials that are not adequately resistant. This erosion can reduce the lifetime of the electrode, leading to decreased performance and higher maintenance requirements.

- **Structural Fatigue:** Repeated cavitation could induce structural fatigue in the electrode material, especially at high rotational speeds, causing eventual breakdown or reduced conductivity due to micro-cracking.

### 2. Electrolyte Degradation:

- **Unintended Side Reactions:** Cavitation can induce extreme local conditions that may inadvertently trigger undesirable side reactions within the electrolyte. For example, excessive cavitation energy could cause the breakdown of certain electrolyte components, producing impurities or gases (such as chlorine or hydrogen in a saline electrolyte) that reduce battery efficiency and complicate the battery chemistry.

12/3/2024





12/3/2024

## Spinning Disc Reactors (SDRs) Alternatives

There are several alternatives to using cavitation for enhancing reaction kinetics in chemical processes. These alternatives also focus on improving mass transfer, mixing, and energy input to accelerate chemical reactions, depending on the specific system and requirements. Here are some prominent alternatives:

### 1. Ultrasound (Sonochemistry Without Cavitation)

- **How It Works:** Ultrasound generates high-frequency sound waves that produce pressure variations in a liquid, improving molecular movement and facilitating reaction rates.
- **Advantages:** Ultrasound enhances micro-mixing and can reduce the activation energy of reactions, without necessarily creating the intense bubble implosions associated with cavitation. It provides gentle mixing, suitable for delicate reactions where extreme energy bursts are undesirable.
- **Applications:** Frequently used in emulsification, polymerization, and catalysis to ensure uniform mixing without physical wear or damage.

### 2. Microwave Heating

- **How It Works:** Microwave radiation directly heats polar molecules by causing them to oscillate, producing rapid and uniform heating within the reaction mixture.
- **Advantages:** Microwave heating provides volumetric heating, which is faster and more energy-efficient than conventional heating methods, especially in heterogeneous systems. This can significantly increase reaction rates by ensuring uniform temperature and energy distribution.
- **Applications:** Widely used in organic synthesis, nanomaterial production, and food processing to achieve higher efficiency and shorter reaction times.

### 3. High-Shear Mixing

- **How It Works:** High-shear mixers use impellers or rotor-stator systems to create intense local velocity gradients, leading to effective dispersion and small droplet or particle sizes.
- **Advantages:** High-shear mixing enhances mass transfer and dispersion, particularly in immiscible systems, by creating smaller droplets or particles. It is useful for reactions that are mass-transfer limited.
- **Applications:** Utilized in pharmaceuticals, cosmetics, and chemical processing for emulsification, dissolution, and increasing surface area for catalytic reactions.

### 4. Photocatalysis

- **How It Works:** In photocatalysis, light (often UV or visible) is used to excite a catalyst, generating electron-hole pairs that can initiate or accelerate chemical reactions.
- **Advantages:** Photocatalysis allows for activation of reactions at relatively low temperatures and can drive reactions that are difficult to initiate thermally. It also enables the utilization of solar energy for sustainable chemical processes.
- **Applications:** Commonly used in water treatment, air purification, and organic synthesis for energy-efficient oxidation and reduction reactions.

### 5. Electrochemical Activation

- **How It Works:** Electrochemical cells provide direct current to drive non-spontaneous chemical reactions through electron transfer.
- **Advantages:** Electrochemical activation enables precise control over reaction conditions (e.g., electrode potential and current density) and facilitates reactions like oxidation or reduction without the need for additional chemicals.
- **Applications:** Used in electrolysis, electro-organic synthesis, and battery technologies to achieve high efficiency and selectivity.

12/3/2024







## SDR Spinning Disc Reactor

Using cavitation and sonochemistry for fast processing.



12/3/2024





12/3/2024

12/3/2024

